



Note:  
 Depending on building tolerances an overlay of the UW-runner could be necessary!  
 ETICS boards have to be fixed in CW profiles with appropriate device.

