



Note:  
 Depending on building tolerances an overlay of the UW-runner could be necessary!  
 ETICS boards have to be fixed in CW profiles with appropriate device.  
 There need to be an offset of joints between the insulation panels and the Aquapanel<sup>®</sup> Cement Board.

